

Table of Contents

1.	Important Safety Instruction.....	2
1.1.	An Important Notice	2
1.2.	Storage Instruction	4
2.	Product Introduction	5
2.1.	General Characteristics	5
2.2.	Symbols on the LCD Display Panel	7
2.3.	Panel explanation	9
2.4.	Communication Port Explanation	11
3.	Installation and Operation.....	12
3.1.	Unpacking.....	12
3.2.	Selecting Installation Position	13
3.3.	Installation of Casters Cover	14
3.4.	Terminal Block Explanation	20
3.5.	Operation Test and Installation Instruction.....	27
4.	Troubleshooting Guide	38
4.1.	Trouble Shooting	38
5.	Bundled Software Installation Guide	40
5.1.	Hardware Installation	40
5.2.	Software Installation	40
6.	Customer Options Slots.....	41
6.1.	All the below interface cards are with built-in EPO function.....	41
6.2.	R2E(2nd RS-232) card	41
6.3.	RSE(RS-485) card.....	41
6.4.	USE(USB) card	41
6.5.	DCE(Dry Contact) card.....	42
6.6.	SNMP Cards.....	43
6.7.	The Installation of those Interface Cards.....	43
7.	Hot Swappable Battery Replacement	45
8.	Specifications	47

ablerex MSII-RT

Parallel Redundancy On-Line UPS User's Manual

6Kva

1. Important Safety Instruction

1.1. *An Important Notice*

- 1.1.1. To ensure safety in all applications where a UPS is hard wired to the Electrical Supply, ensure that the system is installed by a Qualified Electrical Contractor.
- 1.1.2. The UPS has its own internal energy source (battery). Should the battery be switched on when no AC power is available, there could be voltage at the output terminals.
- 1.1.3. Make sure that the AC Utility outlet is correctly grounded.
- 1.1.4. Do not open the case, as there are no serviceable parts inside. Your Warranty will be void.
- 1.1.5. Do not try to repair the unit yourself; contact your local supplier or your warranty will be void.
- 1.1.6. Please make sure that the input voltage of the UPS matches the supply voltage.
- 1.1.7. Use a certified input power cable with the correct plugs and sockets for the appropriate voltage system.
- 1.1.8. To eliminate any overheating of the UPS, keep all ventilation openings free from obstruction, and do not store "things" on top of the UPS. Keep the UPS 30 cm away from the wall.
- 1.1.9. Make sure the UPS is installed within the proper environment as specified. (0-40°C and 30-90% non-condensing humidity)
- 1.1.10. Do not install the UPS in direct sunlight. Your warranty may be void if the batteries fail.
- 1.1.11. Install the UPS indoors as it is not designed for installation outdoors.
- 1.1.12. Dusty, corrosive and salty environments can do damage to any UPS.
- 1.1.13. Install the UPS away from objects that give off excessive heat and areas that are excessively wet.

- 1.1.14. If liquids are split onto the UPS or foreign objects dropped into the unit, the warranty will be null and void.
- 1.1.15. The battery will discharge naturally if the system is unused for any length of time.
- 1.1.16. It should be recharged every 2-3 months if unused. If this is not done, then the warranty will be null and void. When installed and being used, the batteries will be automatically recharged and kept in top condition.
- 1.1.17. This UPS supports electronic equipment in offices, telecommunications, process control, medical and security applications. Non-authorized technician is not allowed to install the UPS in the following areas.
 - a. Medical equipment directly related to human life
 - b. Elevator, Metro (Subway) system or any other equipment related to human safety.
 - c. Public system or critical computer systems.
- 1.1.18. Do not install the UPS in an environment with sparks, smoke or gas.
- 1.1.19. Make sure the UPS is completely turned off when moving the UPS from one place to another. It might cause electrical shock if the output is not cut completely.
- 1.1.20. The Maintenance Bypass Switch is optional, which is built onto a separate Rack Tower cabinet with the galvanic isolation transformer (GTM-WS) or RacPDU-230 as optional.
- 1.1.21. The UPS also offers CVCF (Constant Voltage Constant Frequency) setting function, but it shall be done by a qualified technician.
 - a. For correct setting and wiring, please contact with your local agent.
 - b. Do not do it by yourself; otherwise, your warranty will be void.
- 1.1.22. This UPS has been designed and constructed to protect your assets from the wide range of power aberrations experienced on Utility power lines today. It is your insurance for reliable, clean and stable voltage supply. It is worth taking care to install the system correctly and to have it maintained correctly by your local dealer.
- 1.1.23. **SAVE THESE INSTRUCTIONS** - This Manual Contains Important Instructions that should be followed during Installation and Maintenance of the UPS and Batteries.
- 1.1.24. Intended for Installation in a Controlled Environment.
- 1.1.25. **CAUTION** - A disconnect switch shall be provided by others for ac output circuit. To reduce the risk of fire, connect only to a circuit provided with

branch circuit over-current protection for 30 amperes rating in accordance with the National Electric Code, ANSI/NFPA 70.

- 1.1.26. CAUTION - To reduce the risk of fire, unit input connect only to a circuit provided with branch circuit over-current protection for 40 amperes rating in accordance with the National Electric Code, ANSI/NFPA 70.
- 1.1.27. Use No. 10 AWG, 60°C copper wire and 22.1 lb-in Torque force when connecting to terminal block.

1.2. Storage Instruction

For extended storage through moderate climate, the batteries should be charged for 12 hours every 3 months by plugging the UPS power cord into the wall receptacle and turn on input breaker on front panel. Repeat this procedure every 2 months under high temperature environment.

2. Product Introduction









2.1. General Characteristics

- 2.1.1. True online architecture continuously supplies in your critical device with a stable, regulated, transient-free pure sine wave AC Power.
- 2.1.2. 20KHz PWM sine-wave topology yields an excellent overall performance. The high crest factor of the inverter handles all high-inrush current loads without a need to upgrade the power rating.
- 2.1.3. Multi-functional LCD/LED panel may display various status of the UPS. The LED display may show UPS working status, Utility Status and UPS Abnormal status, in the mean while, the LCD display may show Input/Output Voltage, Frequency, Load Status, Inner cabinet temperature, and Abnormal Phenomenon.
- 2.1.4. To protect the unit from overloading, it automatically switches to bypass mode in 160 seconds~ 40ms if loading is at 105%~ 150% of rating and in case of overloading at 150% of rating, it switches to bypass mode immediately. It will automatically switch back to inverter mode once overload condition ceases.
- 2.1.5. Should the output becomes short-circuit, the UPS holds the system and cuts the output automatically till the short circuit situation is removed manually.
- 2.1.6. Should the unit become overheated, the internal thermal Switch will detect the heat and switch to bypass mode and vice versa.
- 2.1.7. Fully digitalized control circuit built in the UPS may upgrade the functionality Of the UPS as well as reach a high-level protection of the UPS. Through powerful Communication capability built, it enhances its ability for remote control and monitoring easily.
- 2.1.8. Maintenance-free sealed-type battery minimizes after-sales service.
- 2.1.9. Maintenance bypass switch — it provides an easy and safe troubleshooting or maintenance function when the Utility is normal.
- 2.1.10. Four different working modes, such as Normal, ECO, CF50 and CF60 are provided, which may be widely used in a variety of applications.
- 2.1.11. DC-start function makes sure of the start-up of UPS during power outages.

- 2.1.12. Revolutionary battery management circuit analyzes battery discharging status to adjust battery cut-off point and extend the life of batteries.
- 2.1.13. Intelligent temperature-controlled fan may not only extend the life of the fan, but also reduce annoying noise because of sudden fan spin. It remains your office quiet and comfortable as usual.
- 2.1.14. When UPS is out of order, you may read out the possible fault reason from the LCD screen directly, which may reduce down unnecessary repair task a lot.

2.2. Symbols on the LCD Display Panel

Item	Symbol	Description
1	LINE	Utility or Bypass Source
2		Battery Low
3		Battery Abnormal
4		UPS Overloading
5		UPS Working in specified mode*
6		A Blackout Transfer occurred in UPS Output
7		Bypass Input Abnormal, UPS fails to transfer to bypass, Bypass Abnormal at ECO mode
8		Utility Input Abnormal
9	OFF	UPS Shutoff
10	LINE OFF	UPS Abnormal Lock
11		UPS Flow Chart
12		4 Digits Measurement Display
13		Indicate the item desired to be measured
14		UPS ON Switch or Alarm Silence
15		UPS OFF Switch
16		Previous Page or Setting Change

17		Next Page
18		Special Function Log in /out
19		Enter or Reconfirmed
20		Utility Input Normal LED
21		Bypass Input Normal LED
22		UPS under Redundancy Mode
23		UPS under ECO Mode
24		UPS Fault or Abnormal Warning LED
25	EPO	Emergency Power Off
26	Er05	Battery Weak or Dead
27	Er06	Output Short Circuit
28	Er10	Inverter Over-current
29	Er11	UPS Overheat
30	Er12	UPS Output Overloading
31	Er15	Wrong Procedure to Enter Maintenance Mode
32	Er24	CVCF mode with Bypass input
33	Er**	Other Error code

*The specified modes include Normal mode, ECO mode, CVCF mode, etc..

2.3. Panel explanation


2.3.1. Front Panel Function Explanations



- ① LCD Display
- ② Green LED steadily lights up to indicate that the Utility input voltage is within the window; the LED flashes flickeringly to indicate that the Utility input voltage is within the acceptable window.
- ③ Green LED lights up to indicate Bypass Input is normal.
- ④ Green LED lights up to indicate the UPS has the capability to run under redundancy mode.
- ⑤ UPS is working under ECO (Economic, Line-interactive) mode.
- ⑥ UPS Fault or Abnormal
- ⑦ UPS ON/Alarm Silence
- ⑧ UPS OFF Switch
- ⑨ Special functions log in/out

- ⑩ Go to next page
- ⑪ Go to previous page or change the setting of the UPS.
- ⑫ To re-confirm the change of UPS Setting

2.3.2. Rear Panel Explanation



- A Terminal Resistor for Parallel function
- B RS232 Port
- C External Battery Connector
- D Utility Input Breaker
- E CAN Bus Connection Port for Parallel System
- F Maintenance Bypass Switch and Galvanic Tx. Temperature Sensor
- G Cooling Fan
- H Utility Input &UPS Output Power Connector Connection Port

OUTPUT			INPUT		
G2	N22	L21	G1	N1	L12
L21–N22: UPS OUTPUT G2 : OUTPUT EARTH GROUND			L12–N1: UTILITY INPUT G1 : INPUT EARTH GROUND		

- I Customer Options Slot 1
- J Customer Options Slot 2

2.4. Communication Port Explanation

The Communication port on the UPS provides true RS232 type to communicate with UPS software to remote monitoring the power and UPS status.

With optional interfaces cards, which contains R2E(2nd RS232 plus EPO), RSE(RS485 plus EPO), USE(USB plus EPO), DCE(Dry Contact plus EPO), as well as SNMP/ card, you may combine them according to your demand. However, the R2E card, RSE card and USE card are prohibited to be used Simultaneously.

The bundled software of the UPS is compatible with many operating systems such as Windows 98, & 2000, ME, NT and XP. For other applications like Novell, NetWare, Unix, Linux, please contact your local distributor for a proper solution.

When the optional interface cards are used with onboard RS232 port in communication, the shutdown command at the DCE card & also the EPO signals will get the highest priority in control command, then the SNMP/WEB card , then R2E, RSE and USE get the lowest priority.

2.4.1. True RS232 type


2.4.1.1 The RS232 interface settings

The RS232 interface shall be set as follows:

Baud Rate	2400 bps
Data Length	8 bits
Stop Bit	1 bit
Parity	None

2.4.1.2 The Pin Assignments of true RS232 type

The Pin Assignments of true RS232 type are illustrated as follows:



3. Installation and Operation

The packing condition and the external outlook of the unit should be inspected carefully before installation. Retain the packing material for future use.



3.1. Unpacking

- 3.1.1. Take out the UPS Module, Battery Module or Isolation Transformer with/without Maintenance Bypass Switch from the PE foam.
 - 3.1.2. Unwrap the UPS Module, Battery Module or Isolation Transformer with/Without Maintenance Bypass Switch. .
 - 3.1.3. Standard Package of the UPS Module includes:
 - 1 set of Quick Start Manual
 - 1 set of User's Manual
 - 1 set of UPS communication software with RS232 cable
 - 1 set of accessories pack
 - 3.1.4. Package for the Isolation Transformer with Maintenance Bypass Switch:
 - 1 set of 12 inches long NEMA L5-30P and a 12 inches long NEMA L5-30R
 - 3.1.5. Package for the Isolation Transformer without Maintenance Bypass Switch:
 - 3pcs additional No. 10 AWG, 60°C copper wire
- (p.s. 2pcs 12 inches long NEMA L5-30P and 1pcs 12 inches long NEMA L5-30R are to be used at the input/output terminal block of the UPS. Please refer to Chapter 0 for installation.)

3.2. Selecting Installation Position


It is necessary to select a proper environment to install the unit, in order to minimize the possibility of damage to the UPS and extend the life of the UPS. Please follow the advice below:

1. Keep at least 30cm (12 inches) clearance from the rear panel of the UPS to the wall.
2. Do not block the air-flow to the ventilation openings of the unit.
3. Please check the installation site to avoid overheat and excessive moisture.
4. Do not place the UPS in an environment near dust, corruptive or salty material or flammable objects.
5. Do not expose the UPS to outdoors.




3.3. Installation
3.3.1 Tower installation
3.3.1.1 Power Module + Battery Module

Step1: Installation of the Foot Covers of the Power Module




Step2: Installation of the Power Module and the Battery Module




3.3.1.2 Power Module+ Isolation Transformer Module+ Battery Module

Step1: Installation of the Power Module, Isolation Transformer Module and Battery Module




3.3.2 Rack installation
3.3.2.1 Power Module+ Battery Module


Step1: Installation of the Ear Covers




Step2: Installation of the Ear Covers to Power Module, Isolation Transformer Module and Battery Module




Step3: Installation of the Rail kit to Rack Cabinet






Step5: Installation of the Power Module to the Rack Cabinet




3.3.2.2 Power Module+ Isolation Transformer Module+ Battery Module

Step1: Installation of the Isolation Transformer Module to the Rail



Step2 : Installation of the Power Module to the Rack Cabinet




3.4 Terminal Block Explanation

OUTPUT			INPUT		
G2	N22	L21	G1	N1	L12
L21-N22: UPS OUTPUT			L12-N1: UTILITY INPUT		
G2 : OUTPUT EARTH GROUND			G1 : INPUT EARTH GROUND		


- L12-N1: the terminal for Utility Input to provide the power source when the UPS is working under Utility mode.
- G1: the terminal for UPS Input Ground.
- L21 - N22: the terminals for UPS Output.
- G2: the terminal for UPS Output Ground.

Remarks:

1. When the Isolation transformer and Maintenance Bypass Switch are not installed:
 - a. For 200/220/230/240Vac system, you may connect as shown in below.




(1a1)




(1a2)

2. When the Maintenance Bypass Switch is installed:




(2a1)




(2a2)

3. When the Isolation transformer and Maintenance Bypass Switch are installed:
 - a. For 200/220/230/240Vac system, you may connect as shown in below.




(3a1)




(3a2)

b. For 100/110/115/120Vac system, you may connect as shown in below.




(b)

c. For 200/100Vac, 220/110Vac, 230V/115Vac, or 240/120Vac system, You may connect as shown in below.



(c)


d. For 240/208/120Vac system, you may connect as shown in below.




(d)

4. When the Isolation transformer is installed but Maintenance Bypass Switch isn't installed:

a. For 200/220/230/240Vac system, you may connect as shown in below.




(4a1)




(4a2)

b. For 100/110/115/120Vac system, you may connect as shown in below.




c. For 200/100Vac, 220/110Vac, 230V/115Vac, or 240/120Vac system, You may connect as shown in below.



(c)

d. For 240/208/120Vac system, you may connect as shown in below.



(d)

- To fix the cables, you are recommended to use cable ties.

3.5. Operation Test and Installation Instruction


3.5.1. Start Up in Normal Mode

3.5.1.1 Open the terminal block cover on the rear panel (refer to 2.3.2) Before start the installation, please make sure the grounding is connected properly.

3.5.1.2 Make sure Utility breaker, UPS' Utility breaker is On "Off" position.


3.5.1.3 Make sure the voltage of Utility matches with the input voltage window of the UPS.

3.5.1.4 Connect the Utility separately to the terminal blocks of UPS' Utility and Bypass Inputs. Switch on the Power Breaker of the distribution panel and the breaker of the UPS' Utility Inputs, and then the UPS starts up. Green LEDs ~ 1 & ~ 2 light up to show the Utility and Bypass Inputs are normal and the LCD display will illustrate from drawing A to drawing B.




3.5.1.5 Then, the UPS is on Bypass Mode now and it will proceed self-test automatically. If there is no abnormal message occurred, it means the pre-startup of the UPS is successful and the charger starts to charge the batteries.


3.5.1.6 Press the UPS On Switch (4) for approx. 3 seconds, then the Buzzer sounds twice and the LCD display changes from drawing B to drawing C.




3.5.1.7 Then, the UPS is under self-test mode again, the LCD display will illustrate from drawing C to drawing D and remain approx. 4 seconds under battery mode, then illustrate from drawing E1 to drawing F if the self-test is successful.




* It shows "test".



* It shows "OK" in self-test



* It shows "Fail" in self-test



* It shows "220Vac" in Utility Input.

3.5.1.8 In case of failure in self-test, the LCD display will illustrate from Drawing D to drawing E2, then an error code or error status will be shown on the screen.


3.5.1.9 Your start-up operation of the UPS is completely now. Make sure the UPS is plugged onto the wall receptacle for charging at least 8 hours and the batteries of the UPS are fully charged.

3.5.2 Start-up in Battery Mode (Cold Start)


3.5.2.1 Make sure the UPS you have has already been installed at least 1 set(20pcs) of 12V/7AH or 12V/5AH batteries.

3.5.2.2 Push the UPS On Switch (ⓘ) to awake the UPS for approx. 3 seconds, and then the buzzer sounds twice. The LCD display will illustrate from drawing A to drawing G, and keep awake for approx. 10 seconds.


3.5.2.3 Press the UPS On Switch (ⓘ) of the UPS again for about 3 seconds till the LCD display illustrates from drawing G to drawing H, then the UPS will be in self-test Mode. The UPS may offer energy to the output in a minute, and the LCD display illustrates as drawing I. In case of failure in pushing the UPS On Switch in 10 seconds, the UPS will automatically turn off. You then have to go through step 0 to 0 once again.



* It shows "Off", which means the UPS pre-start is successful.





* It shows Utility input is "0" and Utility Abnormal.





3.5.3 Check Measured Values & Figures detected by UPS

3.5.3.1 If you would like to check the measured values & figures detected by the UPS, please use scroll up (↑) and scroll down (↓) key pads. When you use scroll down key pad, the LCD display will illustrate as Drawing C(Voltage from Utility Input) →Drawing I1(Voltage from Bypass Input) → Drawing J(Frequency from Utility Input) →Drawing K(Frequency from Bypass Input) →Drawing L(UPS Output Voltage) →Drawing M(UPS Output Frequency) →Drawing N(UPS Output Load %)→Drawing O(UPS Battery Voltage) →Drawing P(UPS Inner Temperature).




3.5.4 UPS Default Data and Special Function Execution


3.5.4.1 After UPS completely starts up, press  key pad to change the LCD display screen to drawing Q1.



* It shows buzzer "On".



* It shows buzzer "Off".


3.5.4.2 Press  key pad to scroll down the screen and check the UPS settings. The LCD display will show in consequence between Drawing Q1(buzzer) → Drawing R1(Self-test) → Drawing S1(Bypass Voltage Windows) → Drawing T(Output Frequency Synchronization Window) → Drawing U(Inverter Output Voltage) → Drawing V1(UPS Operation Mode) → Drawing W(Output Voltage Micro Tune Value) → Drawing X(UPS Id) → Drawing Y(No. of UPS in Parallel).



* It shows self-test is NOT "on".



* It shows self-test is "On".



* It shows Bypass Voltage is adjusted to narrow one.



* It shows bypass voltage is adjusted to wider one.



* It shows Frequency Window is +/-3Hz.




* It shows inverter output voltage.

V1




* It shows the UPS is operated in "normal mode".

V2



* It shows the UPS is operated in "Eco mode".


V3



* It shows the UPS is operated in "CVCF 50Hz mode".

P.S: If you want to set be a frequency converter, it shall be required by a qualified technician.

V4



* It shows the UPS is operated in "CVCF 60Hz mode".

P.S: If you want to set be a frequency converter, it shall be required by a qualified technician.

W




* It shows Output Voltage Adjustment % from 0% to 3% or -0% to -3%.

X




* It shows UPS Identification Number.




Y



* It shows the UPS is in the No. 1st of parallel systems.

3.5.4.3 Press scroll up  key pad, you may execute special functions. The Functions includes buzzer ON (as drawing Q1), or buzzer OFF (as drawing Q2, Alarm silence for UPS Warning) and self-test OFF (As drawing R1) or self-test ON. (as drawing R2. UPS will execute battery test for 10 seconds. If the self-test is successful, it will show as Drawing E1; otherwise, it will show as drawing E2 & error message in the same time.)

3.5.5 UPS Default Settings and their alternatives

3.5.5.1 Make sure the UPS is not "On" yet. Press On Switch   and scroll down  key pads simultaneously for approx. 3 seconds, the buzzer will sound twice, the LCD display screen shows as drawing Q1, then the UPS is under setting mode now.

3.5.5.2 To scroll down the LCD screen, you may refer to Chapter 0

3.5.5.3 Except Buzzer(as drawing Q1 & Q2) and Self-test(as drawings R1 & R2),

all the rest default settings may be changed by pressing scroll up  key pad.

3.5.5.4 Drawings S1 and S2 mean the bypass input acceptable window, it can be 184Vac~260Vac or 195Vac~260Vac.

3.5.5.5 Drawing T means the bypass frequency window of the Inverter Output, the acceptable setting values are $\pm 3\text{Hz}$ and $\pm 1\text{Hz}$.


3.5.5.6 Drawing U means the acceptable Inverter Output Voltage, of which voltage is 200Vac, 208Vac, 220Vac, 230Vac, or 240Vac.


3.5.5.7 Drawing V1, V2, V3 and V4 mean the operation modes of the UPS, of which alternative is Online, Eco(Economic) mode, fixed 50Hz Output or fixed 60Hz Output.


3.5.5.8 Drawing W means the adjustments of the Inverter Output, which may be calibrated as 0%, +1%, -1%, +2%, -2%, +3%, or -3%.

3.5.5.9 Drawing X means a specified address & position of the UPS when the UPS is in Parallel mode. The settable numbers are from 1st to 4th.

3.5.5.10 Drawing Y means the total numbers of the UPS in parallel. The settable numbers are from 1 to 4.

3.5.5.11 When all the setting changes are done, you have to press enter  key Pad to save all the changes when the LCD screen shows as drawing Z, then, the LCD screen will show as drawing AA to complete the setting changes. If you don't

want to change those settings, you may press "OFF"  key pads for 5 seconds, then the LCD screen turns to Drawing AA directly, which means your setting changes are invalid.




3.5.5.12 Turn Off the breaker of Utility Input.

3.5.5.13 Your Setting changes are complete.


3.5.6 UPS Is Off Due to Unknown Reason and Its Trouble Shooting

3.5.6.1 If there is a serious abnormal condition occurred, the UPS will lock it itself in "OFF" position as shown in drawing AA and a abnormal message will show in the LCD screen.

3.5.6.2 To release the UPS lock, please check those error messages shown in Chapter 2.2 to trouble shoot the problem of the UPS. Otherwise, consult your

local distributor for service. Press Off  key pad for 5 seconds and buzzer will sound twice. Turn Off the Breaker of Utility Input. The UPS lock problem is solved now, but you shall contact with your Local distributor to make sure the error message shown is solved.

3.5.7 Shut Off


3.5.7.1 Press Off  key pad for about 5 seconds, the Inverter output will be turned off, then the output load is supplied by Bypass loop and the LCD screen shows as drawing B.


3.5.7.2 Turn Off the breaker of Utility Input.

3.5.7.3 The UPS is turned off completely.




3.5.8 Maintenance Bypass Mode




3.5.8.1 It is for UPS maintenance only. A Non-authorized technician is not allowed to operate the following procedures. If there is any damage under unauthorized condition, your warranty will be void immediately.

3.5.8.1.1 Press the Off  key pad for approx. 5 seconds, the LCD screen shows as drawing B and the UPS output is on bypass mode.

3.5.8.1.2 Release the cover of the CAM Switch (Maintenance Bypass Switch) first, then turn on the CAM Switch to "Bypass" mode, and at the right-hand upper Corner of the LCD screen will show  sign.

3.5.8.1.3 Turn off the UPS Utility breaker, you then may proceed UPS maintenance now.

3.5.8.1.4 To repeat , you may put the UPS back to normal working mode, then turn back the CAM switch to "INV" mode, fasten back the cover and repeat  to  The UPS will switch back to inverter mode.

3.5.8.1.5 It is required to go through  first, then go through  If you skip , the UPS will alert for 10 seconds to warn that the procedure is abnormal, which may damage the UPS due to uncertain utility status. The UPS will switch back to Inverter mode immediately if you turn the CAM switch back to "INV".




4. Troubleshooting Guide

4.1. Trouble Shooting

When the UPS malfunctions during operation, you may check the followings:

- Are the wirings of input and output correct?
- If the input voltage of the Utility is within the input window of the UPS?

In case problems or symptoms still exist, please proceed the followings for proper adjustment. Should the problem persists, please contact your local distributor for help.

Situation	Check Items	Solution
UPS Red Fault LED lights up	Check the error code shown on the LCD screen 1. Er05,  &  2. Er06, Er10, Er12, Er28 &  3. EPO 4. Er11 5. Er15 6. Er24 7. other error code	1. Check to see if the battery connection is properly done, then re-charge the batteries for 8 hours to see whether the UPS may backup normally; otherwise, consult your local distributor right away. 2. Remove some uncritical load at the UPS output end. If any damage of the coating of AC power cord, please replace a new one. 3. Remove the short circuit occurred at the EPO terminal. 4. Remove the objects blocked onto the ventilation holes. 5. Make sure the UPS is operated normally. If it is on CVCF mode, you have to turn off and turn on the UPS again. 6. When the UPS is on CVCF mode, it is prohibited to have bypass input. You have to turn off the UPS and bypass input and re-start the UPS. 7. Consult your local distributor for help.
UPS fails to offer battery backup or its back up time is shorter than its calculation.		If the backup time is still too short after 8 hours of charge, please contact your local distributor for battery replacement.
UPS locks itself and it can not be turned off.		Please refer to chapter 0 to trouble shoot the problem; otherwise, consult your local distributor for help.

5. Bundled Software Installation Guide

5.1. Hardware Installation

- 1. Connect the male connector of RS232 cable to the UPS communication port.
- 2. Connect the female connector of the RS232 cable to a dedicated RS232 port of the computer.
- 3. For optional interface cards, you may refer to Chapter 6 for installation.

5.2. Software Installation

Please refer to the user's manual of the software for installation.

6. Customer Options Slots

6.1. All the below interface cards are with built-in EPO function.


The pin assignments of the EPO are:



- 6.1.1. To enable the EPO function, please short Pin 1 & 2.




6.2. R2E(2nd RS-232) card

- 6.2.1. CN1 is for RS232 DB9 and CN3 is for EPO.
- 6.2.2. For communication protocol, please refer to Chapter 2.4.1
- 6.2.3. Installation Position: slot1 or slot 2.
- 6.2.4. Adapted flat cable: cable A or cable B
- 6.2.5. For installation, please refer to Chapter 6.7



6.3. RSE(RS-485) card


- 6.3.1. CN1 for EPO, CN2 for RS485 and CN3 for remote power.
- 6.3.2. For communication protocol, please see the definition below:



- 6.3.3. Installation Position: slot1 or slot 2.
- 6.3.4. Adapted flat cable: cable A or cable B
- 6.3.5. For installation, please refer to Chapter 6.7

6.4. USE(USB) card

- 6.4.1. CN1 for USB and CN3 for EPO.
- 6.4.2. For communication protocol, please see the definition below:
Comply with USB version 1.0,1.5Mbps
Comply with USB HID Version 1.0.
The Pin Assignments of the USE card:




- 6.4.3. Installation Position: slot1 or slot 2.
- 6.4.4. Adapted flat cable: cable A or cable B
- 6.4.5. For installation, please refer to Chapter 6.7

6.5. DCE(Dry Contact) card

- 6.5.1. The pin assignments of 10-Pin Terminal:

1	2	3	4	5	6	7	8	9	10
---	---	---	---	---	---	---	---	---	----

- Pin 1: UPS on Bypass mode.
- Pin 2: Utility Normal
- Pin 3: Inverter On
- Pin 4: Battery Low
- Pin 5: Battery Bad or Abnormal
- Pin 6: UPS Alarm
- Pin 7: Common
- Pin 8: Shutdown UPS positive(+) signal
- Pin 9: EPO+
- Pin 10: Ground



- 6.5.2. Installation Position: slot 1 or slot 2
- 6.5.3. To enable the shutdown function, please short Pin 8 & 10.
- 6.5.4. Adapted flat cable: cable A or cable B
- 6.5.5. For installation, please refer to Chapter 6.7

6.6. SNMP Cards

- 6.6.1. SNMP/WEB card
For installation, please refer to the user's manual attached with the card. .
Installation
Position: slot1 or slot 2.
Adapted flat cable: cable A or cable B
For installation, please refer to Chapter 6.7




- 6.6.2. Net Agent II Internal Card
For installation, please refer to the user's manual attached with the card.
Installation
Position: slot 2.
Adapted flat cable: cable C.
For installation, please refer to Chapter 6.7






6.7. The Installation of those Interface Cards

Make sure that the flat cable installed is the same as the one indicated below.



- Please proceed the hardware installation as indicated below.
1. Remove the cover of Slot 1.
 2. Slide in the selected interface card onto the Slot.
 3. Fasten properly the selected interface card.





7. Hot Swappable Battery Replacement

1. Remove the screw covers as well as screws as shown in Step 1.



2. Remove the front panel as indicated in Step 2.




3. Remove the screws of the battery module as shown in Step 3.



4. Unplug the hot swappable battery connectors as shown in Step 4.



5. Remove the battery packs from the battery module as shown in Step 5.



8. Specifications

Model	4500VA	6000VA
INPUT		
Voltage Window	160~280Vac*	
Frequency	45 ~ 65 Hz	
Phase/Wire	Single, Line + Neutral + Ground	
Power Factor	Up to 0.99 at 100% Linear Load	
Current THD	<6% at 100% Linear Load	
OUTPUT		
Voltage Window	200/208/220/230/240Vac Selectable	
Voltage Adjustment	0%; ±1%; ±2%; ±3%	
Voltage Regulation	±2%	
Capacity	4500VA/3150W	6000VA/4200W
Rated Power Factor	0.7 Lagging	
Wave Form	Sine Wave, THD<3% (no load to full Linear load)	
Frequency Stability	±0.2% (Free Running)	
Frequency Regulation	±1%; ±3%	
Transfer Time	0ms	
Efficiency(AC to AC, Normal)	Up to 90%	
Efficiency(AC to AC, ECO)	Up to 97%	
Autonomy	>12 min.	>8 min
DC Start	Yes	
BATTERY		
Type	Sealed Lead Acid Maintenance Free 7AH	
Quantity	20pcs	
Voltage	240Vdc	
Recharge Time	4 hours to 90%	
DISPLAY		
Status On LED + LCD	Line Mode, Backup Mode, ECO Mode, Bypass Supply, Battery Low, Battery Bad/Disconnect, Overload, Transferring with interruption & UPS Fault.	
Readings on LCD	Input Voltage, Input Frequency, Output Voltage, Output Frequency, Load Percentage, Battery Voltage & Inner Temperature.	
Self-Diagnostics	Upon Power-on, Front Panel Setting & Software Control, 24-hour routine checking	
ALARMS		
Audible and Visual	Line Failure, Battery Low, Transfer to Bypass, System Fault Conditions	

PHYSICAL	
Dimensions(WxDxH)mm	440x88x660(UPS Module)
Input/Output Connection	Hardwire
External Battery Connection	Plug-in & Play
Net Weight(Kgs)	24(UPS Module)
Battery Bank Dimensions	Convertible(Rack/Tower)
BBC20J0007(20pcs 12V/7AH)	440x133x660(3U)
Battery Bank Net Weight	Convertible(Rack/Tower)
BBC20J0007 w/o bat./with bat.	18Kgs/68kgs
Isolation Transformer Dimensions	440x88x660(2U)
Isolation Transformer Net Weight	Convertible(Rack/Tower)
with Maintenance Bypass Switch.	42kgs
w/o Maintenance Bypass Switch	41kgs
ENVIRONMENT	
Operating Temperature	0 C to 40 C
Temperature Warning	The battery design life is based on a temperature of 25 C. Ambient temperature above this range will reduce battery life.
Altitude	0~2000m up to 40 C, 3000m up to 35 C
Humidity	90% RH Maximum, Non-Condensing
Noise	<50dB (at 1 meter)
COMPUTER INTERFACE	
Interface Type	Standard RS232 Interface
Communication Slots	2 nd RS232 & EPO**, USB & EPO**, RS485 & EPO**, Relay Contact & EPO, SNMP/WEB Card, etc.
SAFETY CONFORMANCE	
Quality Assurance	ISO9001, ISO14001
Safety Standard	EN62040-1, UL1778
EMC Standard	EN62040-2, EN61000-3-2, EN61000-3-3, FCC Class A
Marks	CE, cUL ,UL

* (160~176Vac at <75% load)

***These cards are not suitable to use simultaneously.

